
# ENGR 4421: Robotics II

Low-Level Motor Control


#### Outline


- Review: H-bridge motor driving circuit
- Review: quadrature encoder
- Review: velocity measurement
- Motor Control using Arduino
- Communication

## H-bridge and DC Motor Control




# H-bridge





# Transistor H-bridge





Transistors drop = 0.7 V

Total drop = 1.4 V


## MOSFET H-bridge


MOSFET drop = 0.1 V






#### Quadrature Encoder





## Calculate Vehicle Velocity




Linear x: 
$$v=rac{V_R+V_L}{2}$$

Angular z: 
$$\omega = rac{V_R - V_L}{L}$$


$$V_L = \dot{ heta}_L \, r$$

$$V_R = \dot{ heta}_R \, r$$

### Arduino Motor Control



#### Communication



- 1. ROS orders "linear x" and "angular z".
- 2. RPi computes desired motor speed.
- 3. Desired motor speed transmitted from RPi to Arduino via serial communication (UART).
- 4. Arduino monitors encoder readings (actual motor speed), then adjust PWM duty cycles.
- 5. Actual speed reported back to RPi via UART